




# Higdon Hardwire Pulsator



## Decoy Operation:

1. Assembly: Make sure that each keeper wire coming from each decoy is slid over the bilge-pump power-source wire. This ensures that the bilge pump is not accidentally lost in the event of detachment. Now the bilge pump is ready to attach to the decoy (diagram at right). Simply snap together.
2. Next, take the wire from the decoy and pump unit and connect it with the end of the wire coming from the mainline battery wire. Also be sure that the keeper cords are attached here as well so that the cords do not accidentally come apart in the event of detachment. Plug the two ends of the cords together and you should hear the unit turn on (cycling on and off).
3. To set-up the Hardwire Plug-N-Hunt Pulsator, simply start at your hunting location and unravel the mainline cord starting with the battery connection clamps. (see diagram below) Work out towards your decoy set-up until you get to the 4-way cord split. Spread each end out accordingly within your decoy spread. The Plug-N-Hunt base unit consists of a main-wire that runs a distance of 60 feet from your blind/hunting location then splits off into four separate wires, each with different lengths (10', 20', 30', 30' etc.). It is recommended that you spread each individual Pulsator Decoy Butt out as much as possible to give you more surface water-ripple coverage.



## Decoy Cleaning Maintenance

1. The bilge pumps and pipes can easily be taken off the decoy for cleaning in case of debris clogging up the bilge pump.
2. To clean, simply unsnap the bilge from the bottom of the decoy.
3. Clean out grass and debris.
4. Once the bilge is running properly, snap bilge pump back on.

## Other tips:

- The optional clear rubber tubing piece can be inserted into the discharge pipe for varying differences in water spray, decoy movement and ripple effect.
- Within the box are 4 floats. Add these to the end of each secondary line if you want to remove the decoys and leave the wiring in place for a return hunt. These are also handy in being able to find the end plugs during set-up. (See float & weight image at right.)
- Adjust the attached cord weights to the appropriate water depth you will be hunting. This will keep the Pulsators in a somewhat fixed location and not tangling with other decoys. (See float & weight image at right.)
- Your 4-Unit Hardwire System can also be expanded to accept additional units. There are many options and add-ons available at [www.higdondecoys.com](http://www.higdondecoys.com) including popular motion decoys such as the Splashing-Flasher, Floating Flasher, Mallard & Canada Swimmer Decoys and others. Visit the site for optional timers, extensions and more in-depth information about your Hard-Wire System.
- Please visit our website, [www.higdondecoys.com](http://www.higdondecoys.com) for product display, set up and parts.

